

Double Link Kit Installation

Double Link Kit includes the following:

Two Polythene Links

Four 10" hex screws & four washers

Four Green UHMW Blocks

* 3/8 Nut needed with socket wrench to tighten UHMW blocks

